


***LP-1 Series***

# **THERMAL TRANSFER / DIRECT THERMAL BAR CODE PRINTER**

## **SERVICE MANUAL**



# LP-1 Series

## Bar Code Printer Service Manual

---

### TABLE OF CONTENT

<b>1. FUNDAMENTAL OF THE SYSTEM.....</b>	<b>1</b>
1.1. Overview.....	1
<b>2. ELECTRONICS.....</b>	<b>5</b>
2.1 Summary of Board Connectors.....	5
2.2 Interface Pin Configuration.....	7
<b>3. MECHANISM .....</b>	<b>8</b>
3.1 Remove the Lower Front Panel .....	8
3.2 Remove the Electronics Cover .....	9
3.3 Replacing the Platen Roller Assembly.....	10
3.4 Replacing the Print head ASS'Y .....	12
3.5 Replacing the LCD Panel Cover Assembly .....	13
3.6 Replacing the Label Supply Spindle .....	15
3.7 Replacing the Power Supply Unit.....	17
3.8 Replacing the Internal Rewinder DC Motor .....	18
3.9 Replacing the Internal Full Rewinder Kit (Option).....	19
3.10 Replacing the Main Board.....	23
3.11 Replacing the Stepping Motor Assembly .....	24
3.12 Replacing the Gap/Black Mark Sensor Module .....	25
3.13 Cutter Module Installation (Option) .....	27
3.14 Peel-off Kit Installation (Option) .....	29
3.15 Slot-in Wireless Housing Installation (Option) .....	34
3.16 GPIO Interface Assembly Installation (Option).....	36
3.17 Bluetooth Module Installation (Option) .....	39
<b>4. Troubleshooting .....</b>	<b>41</b>
4.1 Common Problems .....	41
4.2 Mechanism Fine Adjustment to Avoid Ribbon Wrinkles .....	44
4.2.1 Print Head Pressure Adjustment Knob .....	44
4.2.2 Use Ribbon Tension Adjustment Knob Module to avoid Ribbon Wrinkles.....	45
4.2.3 Mechanism Fine Adjustment to Avoid Ribbon Wrinkles .....	46
<b>5. MAINTENANCE.....</b>	<b>48</b>
<b>UPDATE HISTORY .....</b>	<b>50</b>

# LP-1 Series

## Bar Code Printer Service Manual

---

## 1. FUNDAMENTAL OF THE SYSTEM

### 1.1. Overview

Front View

For LP-1 Series



- 1.** Printer status LED indicator
- 2.** Icons and LED indicators (Print head/ Ribbon/ Label/ RF status)
- 3.** Front panel buttons (Pause/ Feed)
- 4.** Media view window
- 5.** Paper exit chute
- 6.** Media cover handle

# LP-1 Series



## Bar Code Printer Service Manual

---

### For LP-1 Series



- 1. Printer status LED indicator
- 2. LCD touch panel display
- 3. Select and navigational keys (refer to description as below)
- 4. Media view window
- 5. Paper exit chute
- 6. Media cover handle


Keys	Function
Select keys 	The labels on the footer of the UI will explain the function for left and right soft key. Check the labels on the footer of the UI screen. The meaning of the select keys will vary.
Navigational keys 	Used to select icons, menu selection and navigation in the UI.

# LP-1 Series


## Bar Code Printer Service Manual

### Interior View

#### For LP-1 Series



1. Ribbon rewind spindle
2. Print head pressure adjustment knob
3. Print head release lever
4. Ribbon supply spindle
5. Label roll guard
6. Label supply spindle
7. External label entrance chute
8. 3" core adapter
9. Liner securing clip (Optional kit of Peel-off module ass'y)
10. Liner rewind spindle (Optional kit of Peel-off module ass'y)
11. Media guide bar (Optional kit of Peel-off module ass'y)
12. Damper
13. Ribbon end sensor
14. Print head
15. Front label guide
16. Platen roller
17. Black mark sensor (shown as ↓)



## LP-1 Series

### Bar Code Printer Service Manual

---

# LP-1 Series

## Bar Code Printer Service Manual

---

### Rear View

#### For LP-1 Series




1. External label entrance chute
2. Power switch
3. USB client interface (High speed mode)
4. USB host interface
5. RS-232C interface
6. Slot-in Wi-Fi or GPIO interface (Option)
7. Ethernet interface
8. Power cord socket

**Note:**  
The interface picture here is for reference only. Please refer to the product specification for the interfaces availability.

## 2. ELECTRONICS


### 2.1 Summary of Board Connectors

#### Main board for LP-1 Series



## LP-1 Series

### Bar Code Printer Service Manual


Connector	Description			Remark
1	Power switch connector			SW1
2	Power supply (24V DC) connector			DCIN2
		Pin name	CONFIGURATION	
		1	+24V	
		3	GND	
3	USB client connector			USB1
4	USB host connector			USB2
5	RS-232C connector			RS1
6	Ethernet connector			LAN1
7	RTC battery connector			BT1
8	LED & key & touch-function connector			CON19
9	Head open sensor connector			CON1
10	LCD panel (Interface 1, SPI LCD) connector			CON23
11	Micro processor			-
12	LCD panel (Interface 2, parallel LCD) connector			CON9
13	Liner rewinder connector			CON26
14	Gap receiver sensor connector			CON5
15	Gap emitter sensor connector			CON20
16	RFID connector			CON8
17	Wi-Fi / Bluetooth connector			CON13
18	Buzzer			BZ1
19	Ribbon end sensor connector			CON11
20	Ribbon encoder sensor connector			CON12
21	Black mark sensor connector			CON21
22	Peel-off sensor connector			CON10
23	Cutter connector			CON6
24	Print head connector			CON24
25	Stepping motor connector			CON16

## 2.2 Interface Pin Configuration


### RS-232C

PIN	CONFIGURATION
1	+5 V
2	TXD
3	RXD
4	CTS
5	GND
6	RTS
7	N/C
8	RTS
9	N/C

### USB Device

	PIN	CONFIGURATION
	1	N/C
	2	D-
	3	D+
	4	GND

### USB Host

	PIN	CONFIGURATION
	1	5V
	2	D-
	3	D+
	4	GND


### Ethernet

PIN	CONFIGURATION
1	Tx+
2	Tx-
3	Rx+
4	N/C
5	N/C
6	Rx-
7	N/C
8	N/C

### 3. MECHANISM


#### 3.1 Remove the Lower Front Panel

1. Open the media cover.
2. Move the tab outward then pull the panel inward to remove the lower front panel.




Lower front panel

3. Reassemble the parts in the reverse procedures.  
Note: When install the lower front panel, please attach the hook along the protrusion of print head mechanism.




#### 3.2 Remove the Electronics Cover


1. Open the printer right side cover and remove two screws on the electronic cover as indicated.



2. Turn the printer to left side and remove two screws on the electronic cover.




3. Remove the electronic cover.



4. Reassemble the parts in the reverse procedures.

### 3.3 Replacing the Platen Roller Assembly

1. Open the media cover.
2. Push the print head release lever to open the print head mechanism.




3. Refer to section 3.1 to remove the lower front panel.




Lower front panel


4. Release the platen roller bush tabs then push it to the end of mechanism on both sides as indicated.



Platen roller bush tabs



5. Pull up and remove platen roller assembly.




Platen roller assembly


6. Remove/Replace the platen roller assembly.  
7. Reassemble the parts in the reverse procedures.

#### 3.4 Replacing the Print head ASS'Y


1. Open the media cover.
2. Push the print head release lever to open the print head mechanism.



3. Release the print head assembly by removing one screw as indicated.



4. Remove/Replace the print head assembly.




Print head module assembly spare part

5. Reassemble the parts in the reverse procedures.

### 3.5 Replacing the LCD Panel Cover Assembly

1. Refer to section 3.2 to remove the electronics cover.
2. Remove one screw on left front panel cover and disconnect two connectors on LCD panel.



3. Remove the six screws and one contact spring connected on LCD panel.



**LP-1 Series  
(Touch panel)**

4. Remove/Replace the LCD panel cover assembly.


## LP-1 Series

### **Bar Code Printer Service Manual**

---

5. Reassemble the parts in the reverse procedures.

Note: When reassemble the parts, please install the cables through the loading path as below.




#### 3.6 Replacing the Label Supply Spindle


1. Refer to section 3.2 to remove the electronics cover.



2. Remove the two screws on slot-in Wi-Fi/ GPIO interface board (if module installed).
3. Remove the two screws and two hexagon screws on interface board.



4. Remove four screws and all connectors on the main board.






## LP-1 Series


### Bar Code Printer Service Manual

---

5. After removed the main board, please loosen the two screws as indicated to release label supply spindle.



6. Remove/Replace the label supply spindle.



Label supply spindle


7. Reassemble the parts in the reverse procedures.

## LP-1 Series


### Bar Code Printer Service Manual

#### 3.7 Replacing the Power Supply Unit

1. Refer to section 3.2 to remove the electronics cover.
2. Remove three screws as indicated below.




3. Remove one screw on main board as indicated to remove power supply unit.



4. Remove/Replace the power supply unit.
5. Reassemble the parts in the reverse procedures.

#### 3.8 Replacing the Internal Rewinder DC Motor

1. Refer to section 3.2 to remove the electronics cover.
2. Remove two screws and one cable connector on rewinder board as indicated.




DC motor module


3. Remove/Replace the DC motor module.
4. Reassemble the parts in the reverse procedures.

#### 3.9 Replacing the Internal Full Rewinder Kit (Option)

1. Refer to section 3.2 to remove the electronics cover.
2. Install the internal full rewriter module on the positioning holes and fix the module by fasten three screws as indicated.



Positioning holes




Screws

## LP-1 Series


### Bar Code Printer Service Manual

---

3. Install the internal full rewinder module cable on the main board cable socket as indicated.



4. Reassemble the electronics cover.
5. Open the media cover and install the rewinder spindle guard.




Rewinder spindle guard

## LP-1 Series

### Bar Code Printer Service Manual


---

6. Install the media guard kit.




Media guard kit

7. Remove the lower front panel.



8. Install and fix the lower front panel for internal rewriter by fasten two screws as indicated.



## LP-1 Series

### **Bar Code Printer Service Manual**

---


9. Complete the installation of internal full rewinder kit.




10. Reassemble the parts in the reverse procedures.

#### 3.10 Replacing the Main Board

1. Refer to section 3.2 to remove the electronics cover.
2. Remove the two screws on slot-in Wi-Fi/ GPIO interface board (if module installed).
3. Remove the two screws and two hexagon screws on interface board.




4. Remove four screws and all connectors from the main board.



5. Remove/Replace the main board.
6. Reassemble the parts in the reverse procedures.

#### 3.11 Replacing the Stepping Motor Assembly

1. Refer to section 3.2 to remove the electronics cover.
2. Remove four screws and one connector on the stepping motor assembly.



3. Remove/Replace the stepping motor assembly (including gears and stepping motor).




Stepping motor assembly

4. Reassemble the parts in the reverse procedures.


#### 3.12 Replacing the Gap/Black Mark Sensor Module

1. Refer to section 3.2 to remove the electronics cover.
2. Disconnect the gap/black mark sensor connectors from the main board.



Gap/Black mark  
sensor connectors

3. Open the media cover and push the latch as indicated, then push out the media sensor module to electronic side.




## LP-1 Series

### **Bar Code Printer Service Manual**

---

4. Remove/Replace the gap/black mark sensor.



Media sensor module assembly

5. Reassemble the parts in the reverse procedures.


#### 3.13 Cutter Module Installation (Option)

1. Refer to section 3.1 to remove the lower front panel.




Lower front panel

2. Install cutter module cable on printer cable socket as indicated.



Cable socket

3. Fasten the two screws on printer mechanism as indicated.



Screws

## LP-1 Series

### Bar Code Printer Service Manual

---

4. Close cutter module and fasten one shoulder screw to fix hinge.  
Note: Please make sure shoulder screw did not interfere with hinge.




5. Remove/Replace the cutter module.
6. Reassemble the parts in the reverse procedures.



Cutter module assembly

#### 3.14 Peel-off Kit Installation (Option)

Peel-off Kit parts list:



## LP-1 Series

### Bar Code Printer Service Manual

---

#### A. Peel-off Sensor Module Installation


1. Refer to section 3.1 to remove the lower front panel.



Lower front panel

2. Install peel-off sensor module cable on printer connector as indicated.

Note: Please push the cable to bottom side to prevent media stuck when peeling the label.





Connector

3. Place the peel-off sensor module on locating holes and fix two screws and one shoulder screw as indicated.



Locating holes



Screws

## LP-1 Series

### Bar Code Printer Service Manual

---



4. Close the peel-off sensor module and complete installation.



5. Remove/Replace the peel-off sensor module by the above reverse procedures.

#### B. Rewind Spindle and Media Guide Bar Installation

1. Refer to section 3.2 to remove the electronic cover.
2. Push the media guide bar cover by 3kg ~ 5kg strength on the printer electronic side as indicated.



Media Guide Bar Cover will be partially released on the printer middle plate.

## LP-1 Series


### Bar Code Printer Service Manual

---

3. Remove the media guide bar cover by hand.



4. Remove the black plastic cover by push both sides of cover as indicated.



5. Install the rewind spindle and media guide bar on electronic side.




## LP-1 Series

### Bar Code Printer Service Manual

---


6. Fasten three screws on rewind spindle and media guide bar module as indicated.



7. Disconnect the power cord than insert the rewriter power cable to the main board socket as indicated.



8. Remove/Replace the rewind spindle and media guide bar module.




Rewind Spindle and Media Guide bar module


9. Reassemble the parts in the reverse procedures.

#### 3.15 Slot-in Wireless Housing Installation (Option)

1. Refer to section 3.2 to remove the electronic cover.
2. Take off the slot-in wireless interface board by removing two screws on rear of printer.



3. Install the slot-in wireless housing on the rear of the printer and fix two screws as indicated.




## LP-1 Series

### Bar Code Printer Service Manual

---

4. Connect the slot-in wireless transfer module housing board cable to the main board as indicated.




Slot-in Wi-Fi module with  
antenna and transfer board

5. Remove/Replace the Slot-in Wi-Fi module.
6. Reassemble the parts in the reverse procedures.

#### 3.16 GPIO Interface Assembly Installation (Option)


GPIO Interface Assembly Parts list:




## LP-1 Series

### Bar Code Printer Service Manual




1. Refer to section 3.2 to remove the electronic cover.
2. Take off the slot-in wireless interface board by removing two screws on rear of printer.



3. Install two copper pillars on main board.




4. Remove two cable connectors from the main board and insert GPIO transfer cables, then connect two removed cables to GPIO transfer connectors as indicated.




## LP-1 Series

### Bar Code Printer Service Manual

5. Fasten two screws on GPIO fix board first. Then, aligning the GPIO board to the two locating holes on GPIO fix board and fasten another two screws as indicated.
6. Insert the rest connector of GPIO transfer cable to GPIO board.




7. Fix two screws and two hexagon screws on GPIO interface board to complete installation.





8. Reassemble the parts in the reverse procedures.

#### 3.17 Bluetooth Module Installation (Option)

1. Refer to section 3.2 to remove the electronic cover.
2. Remove one screw on the panel assembly as indicated.



3. Open the panel assembly and Install the Bluetooth module by fix the two screws as indicated. Next, close the panel assembly.




## LP-1 Series

### Bar Code Printer Service Manual

---

4. Connect the Bluetooth module cable on the main board as indicated.



Cable connector

5. Remove/Replace the Bluetooth module.



Bluetooth module

6. Reassemble the parts in the reverse procedures.

### 4. Troubleshooting

#### 4.1 Common Problems

The following guide lists the most common problems that might be encountered when operating this bar code printer. If the printer still does not function after all suggested solutions have been invoked, please contact the Customer Service Department of your purchased reseller or distributor for assistance.

Problem	Possible Cause	Recovery Procedure
<b>Power indicator does not illuminate</b>	<ul style="list-style-type: none"> <li>* The power cord is not properly connected.</li> <li>* The power switch is closed.</li> </ul>	<ul style="list-style-type: none"> <li>* Plug the power cord in printer and outlet.</li> <li>* Switch the printer on.</li> </ul>
<b>Carriage Open</b>	<ul style="list-style-type: none"> <li>* The printer carriage is open.</li> </ul>	<ul style="list-style-type: none"> <li>* Please engage the release levers.</li> </ul>
<b>No Ribbon</b>	<ul style="list-style-type: none"> <li>* Running out of ribbon.</li> <li>* The ribbon is installed incorrectly.</li> </ul>	<ul style="list-style-type: none"> <li>* Supply a new ribbon roll.</li> <li>* Please refer to the steps in user's manual to reinstall the ribbon.</li> </ul>
<b>No Paper</b>	<ul style="list-style-type: none"> <li>* Running out of label.</li> <li>* The label is installed incorrectly.</li> <li>* Gap/black mark sensor is not calibrated.</li> </ul>	<ul style="list-style-type: none"> <li>* Supply a new label roll.</li> <li>* Please refer to the steps in user's manual to reinstall the label roll.</li> <li>* Calibrate the gap/black mark sensor.</li> </ul>
<b>Paper Jam</b>	<ul style="list-style-type: none"> <li>* Gap/black mark sensor is not set properly.</li> <li>* Make sure label size is set properly.</li> <li>* Labels may be stuck inside the printer mechanism.</li> </ul>	<ul style="list-style-type: none"> <li>* Calibrate the media sensor.</li> <li>* Set media size correctly.</li> <li>* Remove the stuck label inside the printer mechanism.</li> </ul>
<b>Take Label</b>	<ul style="list-style-type: none"> <li>* Peel function is enabled.</li> </ul>	<ul style="list-style-type: none"> <li>* If the peeler module is installed, please remove the label.</li> <li>* If there is no peeler module in front of the printer, please switch off the printer and install it.</li> </ul>
* Check if the connector is plugging correctly.		

## LP-1 Series

### Bar Code Printer Service Manual

<b>Not Printing</b>	<ul style="list-style-type: none"> <li>* Check if interface cable is well connected to the interface connector.</li> <li>* Check if wireless or Bluetooth device is well connected between host and printer.</li> <li>* The port specified in the Windows driver is not correct.</li> </ul>	<ul style="list-style-type: none"> <li>* Re-connect cable to interface or change a new cable.</li> <li>* Please reset the wireless device setting.</li> <li>* Select the correct printer port in the driver.</li> <li>* Clean the printhead.</li> <li>* Printhead's harness connector is not well connected with printhead. Turn off the printer and plug the connector again.</li> <li>* Check your program if there is a command PRINT at the end of the file and there must have CRLF at the end of each command line.</li> </ul>
<b>Memory full ( FLASH / DRAM )</b>	<ul style="list-style-type: none"> <li>* The space of memory is full.</li> </ul>	<ul style="list-style-type: none"> <li>* Delete unused files in the memory.</li> </ul>
<b>Poor Print Quality</b>	<ul style="list-style-type: none"> <li>* Ribbon and media is loaded incorrectly</li> <li>* Dust or adhesive accumulation on the print head.</li> <li>* Print density is not set properly.</li> <li>* Printhead element is damaged.</li> <li>* Ribbon and media are incompatible.</li> <li>* The printhead pressure is not set properly.</li> </ul>	<ul style="list-style-type: none"> <li>* Reload the supply.</li> <li>* Clean the print head.</li> <li>* Clean the platen roller.</li> <li>* Adjust the print density and print speed.</li> <li>* Run printer self-test and check the print head test pattern if there is dot missing in the pattern.</li> <li>* Change proper ribbon or proper label media.</li> <li>* Adjust the printhead pressure adjustment knob.</li> <li>* The release lever does not latch the printhead properly.</li> </ul>
<b>LCD panel is dark and keys are not working.</b>	<ul style="list-style-type: none"> <li>* The cable between main PCB and LCD panel is loose.</li> </ul>	<ul style="list-style-type: none"> <li>* Check if the cable between main PCB and LCD is secured or not.</li> </ul>
<b>LCD panel is dark but the LEDs are light.</b>	<ul style="list-style-type: none"> <li>* The printer initialization is unsuccessful.</li> </ul>	<ul style="list-style-type: none"> <li>* Turn OFF and ON the printer again.</li> <li>* Initialize the printer.</li> </ul>
<b>LCD panel is dark and LEDs are lit on, but the label is feeding forward.</b>	<ul style="list-style-type: none"> <li>* The LCD panel harness connector is loose.</li> </ul>	<ul style="list-style-type: none"> <li>* The LCD panel harness connector is plugged upside down.</li> </ul>
<b>Ribbon encoder sensor doesn't work.</b>	<ul style="list-style-type: none"> <li>* The ribbon encoder sensor connector is loose.</li> </ul>	<ul style="list-style-type: none"> <li>* Fasten the connector.</li> </ul>
<b>Ribbon end sensor doesn't work.</b>	<ul style="list-style-type: none"> <li>* The connector is loose.</li> <li>* The ribbon sensor hole is covered with dust.</li> </ul>	<ul style="list-style-type: none"> <li>* Check the connector.</li> <li>* Clear the dust in the sensor hole by the blower.</li> </ul>
<b>Peel sensor is not working.</b>	<ul style="list-style-type: none"> <li>* Peel sensor is not located on the correct position.</li> <li>* The connector is loose.</li> </ul>	<ul style="list-style-type: none"> <li>* Make sure that the media goes through the Peel sensor.</li> <li>* Plug the connect cable correctly.</li> </ul>
<b>Cutter is not working.</b>	<ul style="list-style-type: none"> <li>* The connector is loose.</li> </ul>	<ul style="list-style-type: none"> <li>* Plug in the connect cable correctly.</li> </ul>
<b>Label feeding is not stable (skew) when printing.</b>	<ul style="list-style-type: none"> <li>* The media guide does not touch the edge of the media.</li> </ul>	<ul style="list-style-type: none"> <li>* If the label is moving to the right side, please move the label guide to left.</li> <li>* If the label is moving to the left side, please move the label guide to right.</li> </ul>

## LP-1 Series


### Bar Code Printer Service Manual

---

<b>Skip labels when printing.</b>	<ul style="list-style-type: none"><li>* Label size is not specified properly.</li><li>* Sensor sensitivity is not set properly.</li><li>* The media sensor is covered with dust.</li></ul>	<ul style="list-style-type: none"><li>* Check if label size is setup correctly.</li><li>* Calibrate the sensor by Auto Gap or Manual Gap options.</li><li>* Clear the GAP/Black mark sensor by blower.</li></ul>
<b>Missing printing on the left or right side of label.</b>	<ul style="list-style-type: none"><li>* Wrong label size setup.</li></ul>	<ul style="list-style-type: none"><li>* Set the correct label size.</li></ul>
<b>RTC time is incorrect when reboot the printer.</b>	<ul style="list-style-type: none"><li>* The battery has run down.</li></ul>	<ul style="list-style-type: none"><li>* Check if there is a battery on the main board.</li></ul>
<b>Multi interface board doesn't work.</b>	<ul style="list-style-type: none"><li>* The installation is incorrect.</li></ul>	<ul style="list-style-type: none"><li>* Check if the board is plugged in the right connector.</li></ul>
<b>Power and Error LEDs are blinking fast.</b>	<ul style="list-style-type: none"><li>* Power switch OFF and ON too fast.</li></ul>	<ul style="list-style-type: none"><li>* Turn off the printer and wait all LEDs are dark, and turn on the printer again.</li></ul>
<b>Wrinkle Problem</b>	<ul style="list-style-type: none"><li>* Printhead pressure is incorrect.</li><li>* Ribbon installation is incorrect.</li><li>* Media installation is incorrect.</li><li>* Print density is incorrect.</li><li>* Media feeding is incorrect.</li></ul>	<ul style="list-style-type: none"><li>* Please refer to chapter 4.2.</li><li>* Please set the suitable density to have good print quality.</li><li>* Make sure the label guide touch the edge of the media guide.</li></ul>
<b>Gray line on the blank label</b>	<ul style="list-style-type: none"><li>* The printhead is dirty.</li><li>* The platen roller is dirty.</li></ul>	<ul style="list-style-type: none"><li>* Clean the printhead.</li><li>* Clean the platen roller.</li></ul>
<b>Irregular printing</b>	<ul style="list-style-type: none"><li>* The printer is in Hex Dump mode.</li><li>* The RS-232 setting is incorrect.</li></ul>	<ul style="list-style-type: none"><li>* Turn off and on the printer to skip the dump mode.</li><li>* Re-set the RS-232 setting.</li></ul>

## 4.2 Mechanism Fine Adjustment to Avoid Ribbon Wrinkles

### 4.2.1 Print Head Pressure Adjustment Knob



The print head pressure adjustment knob has 6 levels of adjustment for 1~2" and 3~4" media widths. Because the printer's paper alignment is to the left side of mechanism, different media widths require the different pressure to print the label correctly. Therefore, it may require adjusting pressure to get the best print quality.

## LP-1 Series

### Bar Code Printer Service Manual

---

#### 4.2.2 Use Ribbon Tension Adjustment Knob Module to avoid Ribbon Wrinkles

Ribbon Tension Adjustment Knob has five positions for adjustment. Because the printer's ribbon alignment is to the left side of mechanism, different ribbon or media widths require different ribbon tension to print correctly. Therefore, it may require to adjust the ribbon tension adjustment knob to avoid wrinkle and get your best print quality.





Ribbon Tension Adjustment Knob

## LP-1 Series

### Bar Code Printer Service Manual

#### 4.2.3 Mechanism Fine Adjustment to Avoid Ribbon Wrinkles

This printer has been fully tested before delivery. There should be no ribbon wrinkle presented on the media for general-purpose printing application. Ribbon wrinkle is related to the media width, thickness, print head pressure balance, ribbon film characteristics, print darkness setting...etc. In case the ribbon wrinkle happens, please follow the instructions below to adjust the printer parts.

<p><b>Adjustable Printer Parts</b></p>	<p>Ribbon Tension Adjustment Knob has 5 positions for adjustment. Use flat blade driver to change the ribbon tension position.</p> <div data-bbox="427 761 892 1108" data-label="Image"> </div> <p>Ribbon Tension Adjustment scales</p> <div data-bbox="916 761 1385 1108" data-label="Image"> </div> <p>Ribbon Tension Adjustment Knob</p>
<p><b>Symptom</b></p>	<p>1. Wrinkle happens from label lower right to upper left direction (“”)</p> <p>2. Wrinkle happens from label lower left to upper right direction (“”)</p>
<p><b>Wrinkle Example</b></p>	<div data-bbox="475 1377 783 1765" data-label="Image"> </div> <div data-bbox="869 1388 949 1523" data-label="Image"> </div> <div data-bbox="829 1590 973 1680" data-label="Text"> <p><b>Feed direction</b></p> </div> <div data-bbox="1034 1377 1353 1765" data-label="Image"> </div>

## LP-1 Series

### Bar Code Printer Service Manual

If the wrinkle on the label starts from the lower right side to upper left side, please do following adjustment.


1. Switch the ribbon tension adjustment knob clockwise per 1 level and print the label again to check if the wrinkle is gone.



2. If the ribbon tension adjustment knob has positioned on the level of innermost side but didn't improve the ribbon wrinkle, please switch the print head pressure adjustment knob per 1 level and print the label again to check if the wrinkle is gone.
3. If the wrinkle can't be avoided, please contact the Customer Service Department of your purchased reseller or distributor for service.

If the wrinkle on the label starts from the lower left side to upper right side, please do following adjustment.

1. Switch the ribbon tension adjustment knob counterclockwise per 1 level and print the label again to check if the wrinkle is gone.



2. If the ribbon tension adjustment knob has positioned on the level of outermost side but didn't improve the ribbon wrinkle, please switch the print head pressure adjustment knob per 1 level and print the label again to check if the wrinkle is gone.
3. If the wrinkle can't be avoided, please contact the Customer Service Department of your purchased reseller or distributor for service.

## LP-1 Series

### Bar Code Printer Service Manual


## 5. MAINTENANCE

This session presents the clean tools and methods to maintain your printer.

1. Please use one of following material to clean the printer.

- Cotton swab (Head cleaner pen)
- Lint-free cloth
- Vacuum / Blower brush
- 100% ethanol

2. The cleaning process is described as following

Printer Part	Method	Interval
<b>Print Head</b>	<ol style="list-style-type: none"><li>1. Always turn off the printer before cleaning the print head.</li><li>2. Allow the print head to cool for a minimum of one minute.</li><li>3. Use a cotton swab (Head cleaner pen) and 100% ethanol to clean the print head surface.</li></ol>	Clean the print head when changing a new ribbon roll.
	 <p>The diagram illustrates the print head assembly. It shows a side view of the print head with labels for 'Print Head', 'Element', and 'Head Cleaner Pen'. A callout box provides a magnified view of the 'Element' area, showing the internal structure of the print head.</p>	
<b>Platen Roller</b>	<ol style="list-style-type: none"><li>1. Turn the power off.</li><li>2. Rotate the platen roller and wipe it thoroughly with a cotton swab, or lint-free cloth soaked with clean water.</li></ol>	Clean the platen roller when changing a new ribbon roll.
<b>Tear Bar/Peel Bar</b>	Use the lint-free cloth with 100% ethanol to wipe it.	As needed

## LP-1 Series

### **Bar Code Printer Service Manual**

<b>Sensor</b>	Compressed air blower or vacuum	Monthly
<b>Exterior</b>	Wipe it with water-dampened cloth	As needed
<b>Interior</b>	Brush or vacuum	As needed

**Note:**

- Do not touch printer head by bare hand. If you touch it careless, please use ethanol to clean it.
- Please use 100% Ethanol. DO NOT use medical alcohol, which may damage the printer head.
- Regularly clean the print head and supply sensors once change a new ribbon to keep printer performance and extend print head life.

# LP-1 Series

## Bar Code Printer Service Manual

---

### UPDATE HISTORY

Date	Content	Editor
2018/12/14	Revise Ch. 4.1 Common Problems	Kate
2019/2/11	Revise 3.4 Replacing the Print head ASS'Y Print head module assembly spare part diagram Add Ch.3.15 GPIO Interface Assembly Installation (Option)	Kate
2019/2/19	Revise Ch.3.15 GPIO Interface Assembly Installation (Option)	Kate
2019/10/4	Revise Ch.3.13 Peel-off Kit Installation (Option) Add Ch.3.16 Bluetooth Module Installation (Option)	Kate
2019/10/23	Add Ch.3.9 Replacing the Internal Full Rewinder Kit (Option)	Kate
2019/12/10	Revise Ch.3.14 Peel-off Kit Installation (Option) section B. Rewind Spindle and Media Guide Bar Installation	Kate

## LP-1 Series

### Bar Code Printer Service Manual

---



Email: [info@airtrack.com](mailto:info@airtrack.com)  
Phone: 1-855-235-1718